ROOM AIR CONDITIONER

INDOOR UNIT	OUTDOOR UNIT
AM24A1(B1)E12	UM24A1(B1)E2
AM26A1(B1)B13	UM26A1(B1)B2

SERVICE Manual

AIR CONDITIONER



CONTENTS

1. Precautions

2. Product Specifications

3. Operating Instructions and Installation

4. Disassembly and Reassembly

5. Troubleshooting

6. Exploded Views and Parts List

7. Block Diagrams

8. PCB Diagrams

9. Wiring Diagrams

10. Schematic Diagrams



© Samsung Electronics Co., Ltd. DEC. 1998.
Printed in Korea.
Code No. DB81-10172A(2)

1. Precautions

1. Warning: Prior to repair, disconnect the power cord from the circuit breaker.

2. Use proper parts: Use only exact replacement parts. (Also, we recommend replacing parts rather than repairing them.)

3. Use the proper tools: Use the proper tools and test equipment, and know how to use them. Using defective tools or test equipment may cause problems later-intermittent contact, for example.

4. Power Cord: Prior to repair, check the power cord and replace it if necessary.

5. Avoid using an extension cord, and avoid tapping into a power cord. This practice may result in malfunction or fire.

6. After completing repairs and reassembly, check the insulation resistance. Procedure: Prior to applying power, measure the resistance between the power cord and the ground terminal. The resistance must be greater than 30 megohms.

7. Make sure that the grounds are adequate.

8. Make sure that the installation conditions are satisfactory. Relocate the unit if necessary.

9. Keep children away from the unit while it is being repaired.

10. Be sure to clean the unit and its surrounding area.



Fig. 1-1 Avoid Dangerous Contact



Fig. 1-2 No Tapping and No Extension Cords



Fig. 1-3 No Kids Nearby!



Fig. 1-4 Clean the Unit

MEMO

2. Product Specifications

2-1 Table

Item \ Model					AM24A1(B1)E2		AM26A1(B1)B2	
					INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT
					AM24A1(B1)E12	UM24A1(B1)E2	AM26A1(A1)B13	UM26A1(B1)B2
Type					Wall-Mounting Multi Split			
Perfor-mance	Cooling			BTU/h	12,000	24,000(12,000x2)	12,000	24,000(12,000x2)
	Dehumiditying			l/h	1.9	-	1.9	-
	Air volume Cooling			m^3/min	8.5	-	8.5	-
	Noise	Cooling		dB	38	56	38	56
	Power			V-Hz	1-220-240V~. 50Hz		1-220V~ 60Hz	
Power	Power Consumption	Cooling		W	1,230	2,460(1,230x2)	1,360	2,720(1,360x2)
	Operating Current	Cooling		A	5.3	10.6(5.3x2)	6.3	12.6(6.3x2)
	Power factor	Cooling		%	96.7		98.1	
	Starting current			A	30			
	Power cord(Option)				-	H07RNF2.5	-	H07RNF2.5
					H05RNF(5G 1mm^2)		H05RNF(5G 1mm^2)	
	Fuse capacity			A	3.15	-	3.15	-
Size	Outer dimension	W x H x D		mm	815x298x182	1000x790x310	815x298x182	1000x790x310
				inch	32.08x11.73x7.17	39.37x31.10x12.2	32.08x11.73x7.17	39.37x31.10x12.2
	Weight			kg	9.6	67	9.6	67
	Refrigerant pipe	Liquid		OD(mm)xL(m)	ø6.35x5		ø6.35x5	
		Gas			ø12.7x5		ø12.7x5	
	Drain hose			ID(mm)xL(m)	ø17x2,000			
	Com-pressor	Type			-	Rotary	-	Rotary
		Model name			-	48A124JV1E5	-	48A135IV1E5
		Capacitor			-	30μF x 420VAC	-	25μF x 450VAC
		Motor	Type(model)		-	-	-	-
			Rated output	W	-	1210	-	1210
	Blower	Type			Cross-fan	Propeller	Cross-fan	Propeller
		Motor	Type		Resin	Still	Resin	Still
			Rated output	W	35	60	35	60
Heat exchanger					2Row 12Step	2Row 30Step	2Row 12Step	2Row 30Step
Refrigerant control unit						A,B-UNIT : Capillary Tube		
Freezer oil capacity				cc	-	410	-	410
Refrigerant to change(R-22)				g	-	830x2	-	800x2
Protection device					-	MRA12030-12008	-	MRA12002-9200
Standard Conditions					ISO R5151 Standard		ARI Standard	

• The basic performance test is based on the piping of 5MT. (Be sure to check the installing conditions as extension of the piping may lead to performance degradetion.)

2-2 Dimensions

2-2-1 Indoor Unit



2-2-1 Outdoor Unit



2-3 Refrigerating Cycle Block Diagram



Refrigerating cycle temperature and pressure

Operating Condition			STD Pressure (kg/cm^2G) 3-way valve	Piping Temp.(˚C)		Temp. Condition(˚C)			
				T1	T2	Indoor		Outdoor	
						DB	WB	DB	WB
Cooling	A or B	Standard	5.0~5.2	11	11	27	19	35	24
		Max over load	6.0~6.3	16	15	32	23	43	26
		Low temp.	3.4~3.6	3	2	21	15	21	15
	A + B	Standard	5.0~5.2	12	10	27	19	35	24
		Max over load	6.0~6.3	16	15	32	23	43	26
		Low temp.	3.4~3.6	3	2	21	15	21	15

MEMO

3. Operating Instructions and Installation

3-1 Operating Instructions

3-1-1 Name & Function of Key in remote controller

NO		NAMED OF KEY		FUNCTION OF KEY
1				On/Off Button. Use this button to start and stop air conditioner.
2			▲ (UP)	Temp. up button. If the ▲ button is pressed once, the setting temperature is increased by 1°C
			▼ (DOWN)	Temp. down button. If the ▼ button is pressed once, the setting temperature is decreased by 1°C
3		MODE		Each time you press this button, MODE is changed in the following order.
4		TURBO		Use this button to provide heavy duty cooling & Heating for 30 minutes.
5		OFF		Set up the reserve or cancel the timer on and timer off quickly
6				Use this button for sleep operation. (The SLEEP mode can be selected at COOL and HEAT mode.)
7				Adjusts air flow vertically. Each time you press this button,
8				Each time you press this button, FAN SPEED is changed in the following order.
9	COVER	TIMER	ON TIMER	Set up the time that operation start.
10			OFF TIMER	Set up the time that operation stop.
11			SET	Use this button to reserve the timer on.
12			CANCEL	Use this button to reserve or cancel the timer on and timer off.
13			(UP)	If the button is pressed once, the time increase by one minute during the time set mode, and ten minutes during the timer set mode.
14			(DOWN)	If the button is pressed once, the time decrease by one minute during the time set mode, and ten minutes during the timer set mode.
15			TIME	Without regard to ON/OFF condition in remote controller, use this button to set current time. Adjust the current time using button. (Data can be transmitted after setting up the time)

3-1-2 Name & Function of Key in remote controller

1. AUTO MODE : In this mode, operation COOL mode is selected automatically by the room temperature of initial operation.

Operation Type	Room Temp	
Cool Operation	Tr≥ 24.5°C+ΔT	Compressor ON
	Tr≤ 24°C+ΔT	Compressor OFF

   ΔT= -2°, -1°C, 0°C+1°C+2°C
   ΔT is controlled by setting temperature up / down key of remote controller
   * FAN SPEED : AUTO

2. COOL MODE : The unit operates according to the difference between the setting and room temperature. (18°C~30°C)

3. DRY MODE : Has 3 states, each determined by room temperature.
   The unit operates in DRY mode.
   *Compressor ON / OFF Time is controlled compulsorily(can not set up the fan speed, always breeze).
   *Protective function : Low temperature release. (Prevention against freeze)

4. TURBO MODE : This mode is available in AUTO, COOL, DRY, FAN MODE.
   When this button is pressed at first, the air conditioner is operated “powerful” state for 30 minutes regardless of the set temperature, room temperature.
   When this button is pressed again, or when the operating time is 30 minutes, turbo operation mode is canceled and returned to the previous mode.
   *But, if you press the TURBO button in DRY or FAN mode that is changed with AUTO mode automatically.

5. SLEEP MODE : Sleep mode is available only in COOL mode.
   The operation will stop after 6 hours.
   *In COOL mode : The setting temperature is automatically raised by 1°C each 1hour When the temperature has been raised by total of 2°C, that temperature is maintained.

6. FAN SPEED : Manual (3 step), Auto (4 step) Fan speed automatically varies depending on both the difference between setting and the room temperature.

7. COMPULSORY OPERATION :
   For operating the air conditioner without the remote controller.
   *AUTO : The operating is the same function that AUTO MODE in the remote controller.

8. SWING : BLADE-H is rotated vertically by the stepping motor.

9. Quick OFF TIMER: OFF timer (quick timer) allows reservation or cancel the timer on and timer off quickly
   When OFF timer button is pressed at operating state, LCD displays the polling state sequentially.
   The LCD also displays the time remaining.

10. 24-Hour ON / OFF Real Setting Timer. : The air conditioner is turned ON at a specified time using [ON TIMER].
    OFF TIMER : The air Conditioner is turned OFF at a specified time using [OFF TIMER].
    *ON TIMER : Only timer LED lights on.
    *OFF TIMER : Both timer and operation LED lights on.
    *3 minutes delay timer.

11. SELF Diagnosis

LED DISPLAY				Check Point
operation	TIMER	FAN	Turbo	
■	○	○	○	Interruption of electric power and Power on.
○	■	○	○	Abnormal condition of the room sensor.
■	■	○	○	Abnormal condition of the indoor unit's heat exchanger sensor.
○	○	■	○	Indoor unit fan motor lock.

■ : LED blinking ○ : LED off

12. BUZZER SOUND : Whenever the ON / OFF button is pressed or whenever change occurs to the condition which is set up or select, the compulsory operation mode, buzzer is sounded "beep"

3-2 Installation

3-2-1 Selecting Area for Installation

Select an area for installation that is suitable to the customer's needs.

3-2-1(a) Indoor Unit

1. Make sure that you install the indoor unit in an area providing good ventilation. It must not be blocked by an obstacle affecting the airflow near the air inlet and the air outlet.
2. Make sure that you install the indoor unit in an area allowing good air handling and endurance of vibration of the indoor unit.
3. Make sure that you install the indoor unit in an area where there is no source of heat or vapor nearby.
4. Make sure that you install the indoor unit in an area from which hot or cool air is spread evenly in a room.
5. Make sure that you install the indoor unit in an area away from TVs, audio units, cordless phones, fluorescent lighting fixtures and other electrical appliances (at least 1 meter).
6. Make sure that you install the indoor unit in an area which provides easy pipe connection with the outdoor unit, and easy drainage for condensed water.
7. Make sure that you install the indoor unit in an area which is large enough to accomodate the measurements shown in figure on the next page.

3-2-1(b) Outdoor Unit

1. Make sure that you install the outdoor unit in area not exposed to the rain or direct sun light.
   (Install a separate sunblind if exposed to direct sun light.)
2. Make sure that you install the outdoor unit in area allowing good air moment, not amplifying noise or vibration, especially to avoid disturbing neighbours.
   (Fix the unit firmly if it is mounted in a high place.)
3. Make sure that you install the outdoor unit in area providing good ventilation and which is not dusty. It must not be blocked by any obstacle affecting the airflow near the air inlet and the air outlet.
4. Make sure that you install the outdoor unit in area free from animals or plants.
5. Make sure that you install the outdoor unit in area not blocking the traffic.
6. Make sure that you install the outdoor unit in area easy to drain condensed water from the indoor unit.
7. Make sure that you install the outdoor unit in area which provides easy connection within the maximum allowable length of a coolant pipe (10 meters).
   Note
   1. Add 10 grams of refrigerant (R-22) for every 1 meter if the pipe length exceeds the standard pipe length of 5 meters.
   2. Maintain a height between the indoor and outdoor units of less than 3 meters.
8. Make sure that you install the outdoor unit in an area which is large enough to accommodate the measurements shown in figure on the next page.

3-2-1(c) Remote Control Unit

1. Make sure that you install the remote control unit in an area free from obstacles such as curtains etc, which may block signals from the remote control unit.
2. Make sure that you install the remote control unit in an area not exposed to direct sunlight, and where there is no source of heat.
3. Make sure that you install the remote control unit in an area away from TVs, audio units, cordless phones, fluorescent lighting fixtures and other electrical appliances (at least 1 meter).

Caution

It is harmful to the air conditioner if it is used in the following environments: greasy areas (including areas near machines), salty areas such as coast areas, areas where sulfuric gas is present such as hot spring areas. Contact your dealer for advice.

3-2-2 Installation diagram of indoor unit and outdoor unit

A Indoor unit gas leak test check point



Piping may be laid to the rear, left, right or down .



B Drain hose installation





❶	Piping (Liquid) 1/4"	❻	Clamper tube
❷	Piping (Gas) 1/2"	❼	Installation plate
❸	Installation tube	❽	Pipe-connection
❹	Vinyl tape	❾	Screw
❺	Putty	❿	Drain hose

3-2-2(a) Fixing the Installation Plate



1. Determine the position of the pipe and drain hose hole using the right figure and drill the hole with an inner diameter of 65mm so that it slants slightly downwards.

2. **If you are fixing the indoor unit to a… Then follow Steps…**

Wall	**3.**
Window frame	**4 to 6.**

(Unit : mm)



3. Fix the installation plate to the wall in a manner appropriate to the weight of the indoor unit.

   If you are mounting the plate on a concrete wall with anchor bolts, the anchor bolts must not project by more than 20mm.

(Unit : mm)



4. Determine the positions of the wooden uprights to be attached to the window frame.

5. Attach the wooden uprights to the window frame in a manner appropriate to the weight of the indoor unit.

6. Using tapped screws, attach the installation plate to the wooden uprights, as illustrated in the last figure opposite.

3-2-2(b) Purging the Unit



On delivery, the indoor unit is loaded with an inert gas. All this gas must therefore be purged before connecting the assembly piping. To purge the inert gas, proceed as fol - lows.

Unscrew the caps at the end of each pipe.

Result : All inert gas escapes from the indoor unit.

- **To prevent dirt or foreign objects from getting into the pipes during installation, do NOT remove the caps completely until you are ready to connect the piping.**

3-2-2(c) Connecting the Assembly Cable.



The outdoor unit is powered from the indoor unit via the assembly cable. If the outdoor unit is more than five metres away from the indoor unit, the cable must first be extended to a maximum of ten metres.

1. Extend the assembly cable if necessary.
2. Open the front grille by pulling on the tabs on the lower right and left sides of the indoor unit.
3. Remove the screw securing the connector cover.
4. Pass the assembly cable through the rear of the indoor unit and connect the assembly cable to terminals 1 to 5.
   - Each wire is labelled with the corresponding terminal number.
5. Pass the other end of the cable through the 65mm hole in the wall.
6. Replace the connector cover, carefully tightening the screw.
7. Close the front grille.
8. For further details on how to plug the other end of the assembly cable into the outdoor unit, refer to page 3-10.

3-2-2(d) Installing and Connecting the Indoor Unit Drain Hose

Care must be taken when installing the drain hose for the indoor unit to ensure that any condensa - tion water is correctly drained outside.l When passing the drain hose through the 65mm hole drilled in the wall, check that none of the following situations occur.

The hose must NOT slope upw ards.

The end of the drain hose must NOT be placed in water.

Do NOT bend the hose in different directions.

Keep a clearance of at least 5cm between the end of the hose and the ground.

Do NOT place the end of the drain hose in a hollow.

To install the drain hose, proceed as follows.

1. If necessary, connect the 2-metre extension to the drain hose.
2. If you are using the extension, insulate the inside part of the extension drain hose with a shield.
3. Pass the drain hose under the refrigerant piping, taking care to keep the drain hose tight.
4. Pass the drain hose through the hole in the wall, making sure that it is sloping downwards, as shown in the illustrations above.



The hose will be fixed permanently into position once the whole installation has been tested for gas leaks; refer to page 16 for further details.

3-2-2(e) Outdoor unit installation

GAS LEAK TEST





Check for gas leak from the flare nut connections with leak detector.

WIRING CONNECTION

Two electric cables must be connected to the outdoor unit:

- ***The assembly cable connecting the indoor unit to the outdoor unit.***
- ***The power cable connecting the auxiliary circuit breaker to the outdoor unit.***

1 Remove the terminal board cover on the side of the outdoor unit.

2 Connect the assembly cable to terminals 1 to 5 and connect the power cable to therminals A to B.

► Each wire is labelled with the corresponding terminal number.
► Ensure that the wire number of the indoor unit and the terminal number of the outdoor unit.

3 Connect the earthing wires to the earth terminals.

► Refer to the page opposite for further details on how to check that earthing is correct.

4 Replace the terminal board cover, carefully tightening the screw.

5 connect the power cable to the auxiliary circuit breaker.



Grounding

(The parts for this work are optional.)

- A grounding terminal can be found on the outdoor unit as illustrated.



1. When an existing grounding terminal is avilable.
   (Grounding wire of ø1.6mm or larger<solid wire>or 2mm^2 or larger <standard wire>)



2. Use of a grounding electrode.
   - Specifications of grounding electrode.



3-2-2(f) Flare Modification

• Tools used



Flare modification procedure

1) Cut the pipe using a pipe cutter.



2) Remove burrs at the tip of the pipe cut.

Caution : Burrs not removed may result in leakage of gas.



3) Insert a flare nut into the pipe and modifty flare.





Outer diameter	A(mm)
ø6.35mm	1.3
ø9.52mm	1.8
ø12.7mm	2.0

* Unproper flaring



3-2-2(g) Air Purging

CAUTION

The air in indoor unit and in the pipe must be purged. If air remains in the refrigeration pipes, it will affect the compressor, reduce to cooling/heating capacity, and could lead to a malfuction. Refrigerant for air purging is not charged in the outdoor unit. Use additional refrigerant as shown at the right figure. Each unit must be purged in turn

1. Check the piping connections
2. Connect the charging hose of low pressure side of Manifold gauge to the packed valve having a charging port(1/2" Packed valve)
3. Open the valve of the low pressure side of Manifold gauge counterclockwise for 10 seconds, and then close it to closed position.
4. Check for gas leakage.
   - Check the flare connections for gas leakage.
5. Purge the air from the system.
   - Loosen the liquid side(1/4") flare nut after gas leakage check
   - Open the low pressure side valve of the Manifold gauge for 10 seconds to purge the air from the system. Repeat this three times or more.
   - Tighten the liquid side(1/4") flare nut when the low pressure of the manifold gauge indicates about 0.5Kg/cm^2.
6. Set valve cork of both liquid side and gas side of packed valve to the open position.
7. Mount the valve stem nuts to the 2-way and 3-way valve. And mount the service port cap to 3-way valve
8. Check for gas leakage.
   - At this time, especially check for gas leakage from the 3-way valve's stem nuts, and from the service port cap.





<Structure of 3-way valve>

3-2-2(h) Refrigerant Refill

If connecting pipe of more than 10 metres is installed, additional refrigerant should be charged by extra metre. You don't have to charge additional refrigerant up to 10 metres of connecting pipe.

1. Remove the valve stem cap and service port of 3-way valve.
2. Connect the charging hose of low pressure side of Manifold gauge to the packed valve having a charging port(1/2" Packed valve) as shown at the right figure.
3. Operate the unit at the cooling mode.
4. Slowly open the valve of the low pressure side of Manifold gauge counterclockwise until the low pressure of manifold gauge indicates 4.8 to 5.5 kg/cm^2 at the high cool operation (1-unit operation) and the standard temperature.(for details, see the page 3-14)

   It is recommend that refrigerant should be slowly put in. If the refrigerant is put in too quickly, compressor will be damaged.
5. Stop operation of the air conditioner.
6. Disconnect the charge hose of manifold gauge.
7. Close the cap of each valve.

- Piping length and the height

	Pipe Size		Max.piping length A	Max height B
	LIQUID	GAS		
A-UNIT	1/4"	1/2"	15m	3m
B-UNIT	1/4"	1/2"	15m	3m

Additional refrigerant charge (R22,g)

- When length of the pipe is over 5u by the unit, you should charge the refrigerant Formulas
  A-UNIT : 10gx(La-10)/m
  B-UNIT : 10gx(Lb-10)/m
  (La:the length of A-unit's pipe Lb:the total length of B-unit's pipe)





3-2-2(i) Flare unt fixing torque

Outter diameter	Torque (kg-cm)	
	Fixing Torque	Final Torque
ø6.35(Liquid Side)	160	200
ø12.7(Gas Side)	500	550

3-2-2(j) Pump down

1. Confirm that both the 2-way and 3-way valves are set to the open position.
   (1) Remove the valve stem caps.
   (2) Be sure to use a hexagonal wrench to operate the Gas side valve stems.

2. Operate the unit for 10 to 15 minutes.

3. Stop operation and wait for 3 minutes, then connect the charge set to the service port of the 3-way valve.
   (1) Connect the charge hose with the push pin to the service port.

4. Air purging of the charge hose.
   (1) Open the low-pressure valve on the charge set slightly to air purge from the charge hose.

5. Set the liquid side 2-way valve to the closed position.

6. Operate the air conditioner at the cooling cycle and stop operation immediately after setting the 3-way valve to the closed position when the gauge indicates 0 kg/cm^{2}G.
   If the unit can not be operated at the Cooling Mode(weather is rather cool), operate the unit at the Trubo Mode. So that the unit can be operated.

7. Disconnect the charge set, and mount the both 3-way valve's stem nuts and the service port cap.



Relocation of the air conditioner

- Refer to this procedure when the unit is relocated.

1. Carry out the pump down procedure (refer to the details of 'pump down').
2. Remove the power cord.
3. Disconnect the assembly cable from the indoor and outdoor units.
4. Remove the flare nut connecting the indoor unit and the pipe.
   At this time, cover the pipe of the indoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering.
5. Disconnect the pipe connected to the outdoor unit.
   At this time, cover the valve of the outdoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering.
6. Make sure you do not bend the connection pipes in the middle and store together with the cables.
7. Move the indoor and outdoor units to a new locatioon.
8. Remove the mounting plate for the indoor unit and move it to a new location.

3-2-3 Technical Document

- Cooling Characteristics - Outdoor Temperature

  Indoor Unit(D/WB) : AM24A1(B1)E12 : 27/19, AM26A1(B1)B13 : 27/19.5
  AM24A1(B1)E2 : 240V/50Hz, AM26A1(B1)B2 : 220V/60Hz

Cooling Capacity & Air Outlet Temperature



Current & Low Pressure



4. Disassembly and Reassembly

Stop operation of the air conditioner and remove the power cord before repairing the unit.

4-1 Indoor Unit

No	Parts	Procedure	Remark
1	Front Grille	1) Stop the air conditioner operation and block the main power. 2) Seperate the tape of front. Panel upper.	
		3) Contract the second finger to the left and right handle and pull to open the inlet grille. 4) Take the left and right filter out. 5) Loosen one of the right fixing screw and seperate the terminal cover.	
		6) Open the cover screw and loosen three fixing screws of front grille.	
		7) Pull the upper left and right of discharge softly for the outside cover to be pulled out.	
		8) Pull softly the lower part of discharge and push it up **Caution:** Assemble the front panel and fix the hooks of left and right.	

No	Parts	Procedure	Remark
2	Filter Frame	1) Loosen the left and right screw of the Holder Filter, and Separate the Holder Filter.	
3	Ass'y Tray Drain	1) Do ①② , above. Separate the holder at the rear side of Indoor unit. 2) Take the display PCB out. (Center of indoor unit). 3) Loosen three fixing screws of left and right. 4) Pull tray drain out from the back body.	
4	Main PCB	1) Do " ①② ", above 2) Take all the connector of PCB upper side out. 3) Separate the outdoor unit connection wire from the terminal block. 4) If pulling the Main PCB up, it will be taken out. (Separate the TRANS hook, it before).	

No	Parts	Procedure	Remark
5	Heat Exchanger	1) Do " ①②③④ ", above. 2) Loosen the left screws of the heat exchanger. Lifting the heat exchanger up a little to push the up side for separation from the indoor unit	 
6	Fan Motor and Cross Fan	1) Do " ①②③④⑤ ", above. 2) Loosen the fixing two screws and separate the motor holder. 3) Loosen the fixing screw of motor fan. (By use of M3 wrench) Separate the motor from the fan. Separate the fan motor the left holder bearing.	 

4-2 Outdoor Unit

No	Parts	Procedure	Remark
1	Cabinet	1) Turn off the unit and remove the power cable 2) Remove the top cover. 3) Remove the control box cover. 4) Unplug the ass'y cable. 5) Remove the cabi-side. 6) Remove the cabi-front. * When you assemble the parts, check if the each parts and electric connectors are fixed firmly.	
2	Fan Motor & Propeller Fan	1) Do Procedure 1 above. 2) Remove the nut flange. (Turn to the right to remove as it is a left turned screw) 3) Disassemble the propeller fan.	 

5. Troubleshooting

5-1 Items to be checked first

1) Is the voltage of the power correct?
The input voltage shall be rating Voltage ±10% range.
The airconditioner may not operate properly if the voltage is out of this range.

2) Is the link cable linking the indoor unit and the outdoor unit linked properly?
The indoor unit and the outdoor unit shall be linked by 5 cables.
Check the terminals if the indoor unit and outdoor unit are properly linked by the same number of cables.
Otherwise the airconditioner may not operate properly.

3) When a problem occurs due to the contents illustrated in the table below it is a symptom not related to the malfunction of the airconditioner.

NO	Operation of air conditioner	Explanation
1	The COOL operation indication LED (Green) blinks when a power plug of the indoor unit is plugged in for the first time.	It indicates power is on. The LED stops blinking if the operation ON/OFF button on the remote control unit is pushed.
2	In a COOL operation mode, the compressor does not operate at a room temperature higher than the setting temperature that the IN DOOR FAN should operate. In a HEAT operation mode, the compressor does not operate at a room temperature lower than the setting temperature that indoor fan should operate.	In happens after a delay of 3 minutes when the compressor is reoperated. The same phenomenon occurs when a power is on. As a phenomenon that the compressor is reoperated after a delay of 3 minutes, the indoor fan is adjusted automatically with reference to a temperature of the air blew
3	Fan speed setting is not allowed in AUTO or DRY mode.	The speed of the indoor fan is set to LL in DRY mode. Fan speed is 5 steps is selected automatically in AUTO mode.
4	Compressor stops operation intermittently in DRY mode.	Compressor operation is controlled automatically in DRY mode depending on the room temperature and humidity.
5	Timer LED only of the indoor unit lights up and the air conditioner does not operate.	Timer is being activated and the unit is in ready mode. The unit operates normally if the timer operation is cancelled.
6	The compressor stops intermittently in a COOL mode or DRY mode, and fan speed of the indoor unit decreases.	The compressor stops intermittently or the fan speed of the indoor unit decreases to prevent inside/outside air frozen depending on the inside/outside air temperature.

4) Indoor unit observes operation condition of the air conditioner, and displays self diagnosis details on the display panel.

NO	Display	Self Diagnosis
1	Operating LED blinking (1Hz)	Restore from power failure (input initial power)
2	TIMER LED blinking (1Hz)	Indoor unit Room sensor Error (open or short)
3	OPERATING and TIMER LED blinking (1Hz)	Indoor unit heat exchanger temperature sensor Error (open or short)
4	FAN LED blinking (1Hz)	Indoor fan malfunctioning (for speed is Below 38Orpm)

5-2 Fault Diagnosis by Symptom

5-2-1 No Power (completely dead)-Initial diagnosis

1) Checklist :
   (1) Is input voltage normal?
   (2) Is AC power linked correctly?
   (3) Are connections between primary side, secondary side of the power transformer and PCB good.
   (4) Is output voltage of DC regulator IC KA7812 (IC01) normal? (11VDC-12.5VDC)
   (5) Is output voltage of DC regulator IC KA7805 (IC02) normal? (4.5VDC-5.5VDC)



5-2-2 When the Indoor Unit Fan Does Not Operate. (Initial Diagnosis)

1) Checklist :
   (1) Is the indoor unit fan motor properly connected with the connector (CN73)?
   (2) Is the AC voltage correct?
   (3) Is HALL IC in indoor fan motor properly connected with the connector (CN43)?
   (4) Is the running capacitor properly connected with the terminal?

2) Troubleshooting procedure



5-2-3 When the Outdoor Unit Does Not Operate. (Initial Diagnosis)

1) Checklist :
   (1) Is input voltage normal?
   (2) Is the set temperature of the remote control higher than room temperature in COOL mode?
   (3) Is the POWER IN connector (terminal-tab) linked correctly?
   (4) Is the outdoor unit properly connected with the TERMINAL BLOCK connector(5P)?

2) Troubleshooting procedure
   (1) Checking procedures for the indoor unit.



5-2-4 When the UP/DOWN Louver Moter Does Not Operate. (Initial Diagnosis)

1) Checklist :
   (1) Is input voltage normal?
   (2) Is the UP / DOWN louver motor properly connected with the connector (CN61)?

2) Troubleshooting procedure


Remove power cord and plug in again in approx. 5 seconds.
Is operating lamp blinking?
Y
Check as in the procedure "No Power parts". Refer to page 5-2.
Y
Does operation start when swing button of the remote control unit pushed?
Y
Normal
N
Voltage at pin #33-#36 of micom (ICO4) change?(Squarewave)
N
Micom (IC04) is faulty.
Y
Volatge at pin #10, #11, #12, #13 of IC05 (KID65003) change?(Squarewave)
N
Driver IC05 (KID65003) is faulty.
Y
UP/DOWN louver motor is faulty.

5-2-5 In the mode, When there is no warm air current. Check this first;

(1) Is the set temperature of Remote Control lower than room temperature in Heat mode?
(2) Is the Indoor PCB properly connected with the CN71 connector?


After training on, the heating operation should start in five minutes.
YES
Normal
NO
Is the munber #60 of Micom (IC04) DC 4.8 V?
NO
Abnormal Micom
YES
Is the munber #15 of IC07 (KID65003) LOW?
NO
Abnormal IC07
YES
Is the voltage between CN71 #3 and #4 AC198~264?
NO
Abnormal R73
YES
Abnormal 4way valve of Outdoor Unit. or connecting Cable
4 way valve should be replaced or connecting Cable Check.
PCB should be replaced.

5-2-6 If Operation By Remote Control Unit Is Impossible. (Initial Diagnosis)

1) Troubleshooting procedure


Remove power cord and plug in again approx. 5 Seconds
Is operation lamp blinking?
N
Check as in the procedure "NO Power parts". Refer to page 5-2.
Y
" ♫ " sound heard from the indoor unit when ON/OFF button on the remote control unit pushed?
Y
Normal
N
Voltage of battery less than 2.5V (Remote Control Unit)?
Y
Replace battery.
N
LCD display status of REMOCON normal?
N
LCD is faulty.
Y
Transmission display lamp ( ) blinking when ON/OFF button on the remote control unit pushed?
N
Replace button.
Y
Voltage at PIN #30 of Remocon Micom change?
N
Micom is faulty.
Y
Voltage at collecter of Q601 or Q602 change?
N
Q601(C4375Y) or Q602(C1623Y) is faulty.
IR LED(CL-1L5EU) is faulty.
Y
Voltage at pin #26 of micom (IC04) change (INDOOR UNIT)?
N
Receiver module is faulty.
Y
Micom (IC04) is faulty.

5-3 PCB Inspection

5-3-1 Cautions for Part Replacement

1. The human body carries much static electricity. Before touching a part for repair, replacement or the similar purpose, be sure to touch a grounded metallic portion by hand to let the static electricity go through the matallic portion to the earth. Espectially when handling any micro computer or IC, carefully remove such static electricity before touching them.
2. When repairing any part on a work bench, be sure to place an insulative sheet on the bench and always keep the sheet surface neat without any metal fragments. If any such fragment touches a part, a secondary trouble will possibly be caused in the part.
3. Before replacing any parts, be sure to turn off the power supply. If such replacement is done with the power supply kept on, an electric shock, short circuit or destruction of a part may result.
4. During replacement or repair of a part, carefully handle it : The printed circuit board has fine lead wires (jumper wires) and glass-made parts (diode) on its substrate. So if a circuit board is roughly handled, such lead wires and parts will be easily broken or damaged by bending or shock.
5. When soldering the lead wires of any new part, be sure to polish them using an emery paper or the like before solding them. Since the lead wires of any new part are covered with an oxide film, solder cannot adhere to the lead wires if not polished.
6. When soldering any part, care should be exercised not to apply any high-wattage soldering iron to the part for a long time. Some parts are of so low a heat resistance that they may be broken or have the properties changed if a soldering iron is so applied (Otherwise, the pattern may possibly be separated and raised).
7. The heat of the soldering iron should be transfered to the entire object to be soldered. If the solder pieces are not well fused due to insufficient transfer of the heat from the soldering iron, no satisfactory electrical continuity can be assured even if the soldered objects appear well connected to each other.
8. The solder used should be limited to a minimum. If excessive solder is used, it will cause inter-pattern contact, which may cause malfunction of the circuit.

5-3-2 Procedure

The parts should be replaced in the following procedure.


Check for any faulty part.
Detach the faulty part.
Replace it with a new part.
Check the operation of the new part.
The repair is completed.

5-3-3 Detailed Procedure

No.	Malfunction	Checking point (symptoms)	Causes
1	Pull out the power plug from the AC terminal and confirm the fuse on the PCB assembly	1. Is the fuse blown?	1. Voltage over 2. Indoor unit fan motor short-circuit.
2	Turn the power on. If lamp blinks trouble is not related to the items 1 through 4 on the right.	Voltage check	
		1. AC voltage at both end of transformer Primary? 198 - 264V~	1. Irregular power code or power fuse, or poor wiring.
		2. AC voltage at both end of transformer secondary? 14- 18Vac	2. Transformer is faulty.
		3. DC voltage at OUT and GND of IC01 (KA7812)? 12VDC	3. Power circuit is faulty.
		4. DC voltage at OUT and GND of IC02? 5VDC	4. Power circuit is faulty.
		5. DC voltage at Q201 Base and GND change? squarewave	5. Q201 is faulty. D101~D104 (1N4007x4)
3	Set operating mode when RMC switch pushed. Except for [FAN]mode and [TIMER] mode.	Voltage check	
		1. Voltage of relay (RY71) coil Voltage at pin#12, pin#5 of IC07 : 12VDC	1. Relay(RY 71) coil is open. IC07 is faulty.
		2. Voltage at Terminal Tap (TB71 or 72) and RY71 Terminal N0③. 198- 264V~	2. Relay(RY 71) contactor is faulty.
4	Set operating mode when RMC switch pushed. 1. COOL mode 2. Fan speed [AUTO] 3. Set temperature lower than room temperature 4. Continuously operation.	1. Compressor does not operate.	1. Temperature of Heat exchange is lower. 2. PCB is faulty. 3. Room sensor or Heat exchanger temperature sensor is faulty
5	Set operating mode when RMC switch pushed. 1. [FAN] mode 2. Fan speed [Hi] 3. Continuously operation	1. Voltage at ③⑤ both ends of CN73 : above 180V~ 2. Indoor unit fan motor does not operate.	1. Indoor unit fan motor is faulty. 2. Poor connection of indoor fan motor and connector of RPM sensing (CN43)

5-4 Fault Diagnosis of Major Parts

<table>
<tr><th>Parts</th><th colspan="2">Diagnosis</th></tr>
<tr><td rowspan="3">Temp.Sensor
Heat ex. Sensor</td><td colspan="2">Measure resistance with a tester.</td></tr>
<tr><td>Normal</td><td>8KΩ~27KΩ at ambient temperature (+0°C ~ +30°C)</td></tr>
<tr><td>Abnormal</td><td>∞, 0 Ω … open or short</td></tr>
<tr><td rowspan="5">Indoor Fan Motor</td><td colspan="2">Measure resistance between terminals (CN73) with a tester</td></tr>
<tr><td>Normal</td><td>At ambient temperature (10°C ~ 30°C)
<table>
<tr><th>between</th><th>Resistance</th></tr>
<tr><td>Red, Yellow</td><td>190±10Ω</td></tr>
<tr><td>Red, Blue</td><td>165±10Ω</td></tr>
</table></td></tr>
<tr><td>Abnormal</td><td></td></tr>
<tr><td colspan="2">Measure the voltage between ground and signal wire of the fan motor</td></tr>
<tr><td>Normal</td><td>
<table>
<tr><th>between</th><th>Voltage</th></tr>
<tr><td>Gray, Orange</td><td>05V~4.5V</td></tr>
<tr><td>Yellow, Orange</td><td>5V</td></tr>
</table></td></tr>
<tr><td></td><td>Abnormal</td><td>Abnormal if voltage does not change from 0V to 5V.</td></tr>
<tr><td rowspan="2">Outdoor Fan Motor</td><td>Normal</td><td>At ambient temperature (10°C ~ 30°C)
<table>
<tr><th>between</th><th>Resistance</th></tr>
<tr><td>Black, Yellow</td><td>189±10Ω</td></tr>
<tr><td>Black, Red</td><td>190±10Ω</td></tr>
</table></td></tr>
<tr><td></td><td>Abnormal</td><td>∞, 0 Ω … open or short</td></tr>
<tr><td rowspan="3">Stepping Motor
(UP/DOWN swing motor)</td><td colspan="2">Measure resistance between red wire and each terminal.</td></tr>
<tr><td>Normal</td><td>Approx. 380Ω at ambient temperature (20°C ~30°C)</td></tr>
<tr><td>Abnormal</td><td>∞, 0 Ω … open or short</td></tr>
</table>

6. Exploded Views and Parts List

6-1 Indoor Unit



■ Parts List

No.	CODE NO	Description	Specification	Q'TY		Remark
				AM24A1(B1)E12	AM26A1(B1)B09	
1	DB64-10140A	GRILLE AIR INLET	ABS	1	1	
1-1	DB64-70073A	PANEL CENTER DISPLAY	PC	1	1	
2	DB63-30131A	GUARD AIR FILTER	PP	2	2	
3	DB74-10091A	ASS´Y FILTER	CLEANER/CARBON	(1)	(1)	OPTION
	DB74-10091B	ASS´Y FILTER	CLEANER/CARBON	(1)	(1)	OPTION
4	DB63-10472B	COVER TERMINAL	HIPS	1	1	
5	DB92-70075E	ASS´Y FRONT PANEL	ASS´Y	1	1	
6	DB93-10560B	ASS´Y PCB DISPLAY	ASS´Y(A1-GRILLE)	1(A1)	1(A1)	⚠
	DB93-10561B	ASS´Y PCB DISPLAY	ASS'Y(B1 GRILLE)	1(B1)	1(B1)	
7	DB94-10088A	ASS´Y TRAY DRAIN	ASS´Y	1	1	
7-1	DB95-20138A	ASS´Y STEP MOTOR U/D	DC12V.600GR	1	1	
7-2	DB66-30153A	BLADE-H	HIPS	1	1	
8	DB75-40077A	ASS´Y EVAP	ASS´Y	1	1	
9	DB67-30058C	SPACER EVAP	PVC	1	1	
10	DB61-00011B	HOLDER MOTOR ASS´Y	ASS´Y	1	1	⚠
10-1	DB65-00007A	ASS´Y TERMINAL BLOCK	ASS´Y	1	1	
11	DB31-10078H	MOTOR FAN IN	AMPFS040WTVB	1	1	
12	DB94-30141A	ASS´Y-C-F-FAN	Ø95 X 619.4mm	1	1	⚠
13	DB94-40017A	ASS´Y BEARING	ASS´Y	1	1	
14	DB93-10595A	ASS´Y MAIN PCB	ASS´Y	1	-	⚠
	DB93-10584A	ASS´Y MAIN PCB	ASS´Y	-	1	⚠
15	DB32-10008D	THERMISTOR ASS´Y	ASS´Y	1	1	
17	DB61-10151A	CASE-CONTROL	ABS(94-5V)	1	1	
18	DB61-60093A	BODY-BUSH	HIPS	1	1	
19	DB94-20030D	ASS´Y BACK BODY	ASS´Y	1	1	
20	DB61-40247A	HOLDER PIPE	HIPS	1	1	
21	DB70-10618A	PLATE HANGER	SGCC-M	1	1	

6-2 Outdoor Unit



■ Parts List

No.	CODE NO	Description	Specification	Q'TY		Remark
				UM24A1(B1)E2	UM26A1(B1)B2	
1	DB90-10163D	ASS'Y-WELD FRONT	SC-90073T	1	1	
1-1	DB72-50520A	INSUL FRONT OUT	Foam pu + Foam pE	1	1	
2	DB67-50067A	FAN-PROPELLER	AS+G/F20%	1	1	
3	DB31-10141A	MOTOR-FAN OUT	OSME-606SRC	1	-	⚠
	DB95-20137J	MOTOR-FAN OUT	AMASS-130ZTEC	-	1	⚠
4	DB61-20094A	BASE-MOTOR	SGCC-M	1	1	
5	DB90-10574A	ASS'Y-CABINET-SIDE	SECC-P	1	1	
5-1	DB72-60053A	INSUL SIDE CABI	FOAM PU + FOAM PE	1	1	
6	DB90-40120A	ASS'Y COVER VALVE	ASS'Y	1	1	
6-1	DB63-10433A	COVER-CONTROL	p.p	1	1	
6-2	DB63-10434A	COVER-VALVE	P.P	1	1	
7	DB90-20207A	ASS'Y-BASE OUT	ASM240UE	1	1	
8	DB99-10082A	ASS'Y-VALVE	UM24A1(B1)E2	1	-	
	DB99-10148A	ASS'Y-VALVE	UM26A1(B1)B2	-	1	
8-1	DB62-40101A	VALVE-PACKED 1/2"	1/2"	2	2	
8-2	DB62-40099A	VALVE-PACKED 1/4"	1/4"	2	2	
8-3	DB62-31576A	TUBE CAPI (C)	ID 1.7 x 1000	2	-	
	DB62-31883A	TUBE CAPI (C)	ID 1.7 x 750	-	2	
9	DB63-30027C	GUARD-COND	SC-90073T	1	1	
10	DB93-00028A	ASS'Y CONTROL OUT	UM24A1E2	1	-	⚠
	DB93-40783A	ASS'Y CONTROL OUT	UM26A1B2	-	1	⚠
10-1	DB61-10199A	CASE CONTROL OUT	SGCC-M	1	1	
10-2	DB65-10015A	CLIP-CAPACITOR	SGCC-M	2	-	
	DB65-60008A	CLIP-CAPACITOR	SGCC-M	-	2	
10-3	2501-001062	C-OIL	30µF x 420V	2	-	
	2501-000344	C-OIL	25µF x 450V	-	2	
10-4	DB65-40072B	TERMINAL BLOCK	8P	1	1	
10-5	2501-000398	C-OIL	4µF x 450V	1	-	
	2501-001069	C-OIL	3.5µF x 450V	-	1	
11	DB94-50041A	ASS'Y-PARTITION	SGCC-P	1	1	
11-1	DB72-60099A	INSUL PARTITION	FOAM PU + FOAM PE	1	1	
11-2	DB67-30083A	PARTITION	SGCC-M	1	1	
12	DB90-10616A	ASS'Y CABI UPPER	ASS'Y	1	1	
13	DB95-10062Y	ASS'Y-COMP	48A124JV1E5	2	-	⚠
	DB95-10062W	ASS'Y-COMP	48A1351V1E5	-	2	⚠
13-1	DB73-10004A	GROMMET-ISOLATOR	EPDM	6	6	
13-2	DB60-30028A	NUT-HEXAGON	M8	6	6	
13-3	DB60-30018A	NUT-FLANGE	P10.8	2	2	
13-4	DB63-10165B	COVER-TERMINAL	NORYL	2	2	
13-5	DB47-20001Z	OLP	MRA12030-12008	2	-	
	DB47-20001G	OLP	MRA12002-9200	-	2	
14	DB96-30080A	CONDENSER	ASS'Y	1	1	
15	DB63-30110J	SCREEN-GUARD	P.E.H 100%	1	1	⚠

6-3 Remote Control & PCB Box

6-3-1 Remote Control



■ Parts List

No	CODE NO	Description	Specification	Q'TY	Remark
	DB93-30071F	ASS'Y CODE			
1	DB61-10144A	CASE UP	ABS	1	
2	DB61-10145A	CASE LOW	ABS	1	
3	DB64-20054A	DOOR REMOCON	ABS	1	
4	DB63-10477A	COVER BATTERY	ABS	1	
5	DB74-10084A	FILTER REMOCON	PC	1	
6	DB73-20110B	RUBBER REMOCON	SILICON	1	
7	DB64-40167A	INLAY LCD	PC	1	
8	DB64-40166B	INLAY REMOCON	PC	1	
9	DB68-10775A	LABEL REMOCON	ART 90	1	
10	DB68-10777A	LABEL DOOR	ART 90	1	
11	PH-M2	SCREW TAP	PH-M2	6	
12	DB67-60061A	SPRING BATTERY	SUS 304	1	
13	DB67-60062A	SPRING BATTERY	SUS 304	1	
14	DB67-60063A	SPRING BATTERY	SUS 304	1	
15	90 X 250	PE BAG	90 X 250	1	
16	DB93-40179B	ASS'Y PCB REMOCON		1	
17	DB61-40243A	HOLDER REMOCON	ABS	1	

6-3-2 PCB Box



■ Parts List

No	CODE NO	Description	Specification	Q'TY		Remark
				AM24A1(B1)E12	AM26A1(B1)B13	
1	DB61-10151A	CASE-CONTROL	ABS(94-5V)	1	1	
2	DB93-10584A	ASS'Y MAIN PCB	ASS'Y	-	1	
	DB93-10595A	ASS'Y MAIN PCB	ASS'Y	1	-	
2-1	DB09-10149A	IC - MCU	MB89635R-466	1	1	
2-2	DB32-10008D	THERMISTOR ASS'Y	103AT	1	1	
2-3	DE26-20154A	TRANS-POWER	AC230V DC17V 300mA	1	1	
2-4	2306-000294	C-FILM	CFS 99N 450VAC 155K	1	1	
2-5	3501-001058	POWER-RELAY	DI1U DC12V	1	1	
2-6	DE32-10037A	FUSE	250V 3.15A	1	1	
3	DB93-10560B	ASS'Y PCB DISPLAY	A1-GRILLE	1(A1)	1(A1)	
	DB93-10561B	ASS'Y PCB DISPLAY	B1-GRILLE	1(B1)	1(B1)	

MEMO

7. Block Diagrams

7-1 Micro Computer Block Diagram



8. PCB Diagrams

8-1 Main PCB



■ PART LIST

No	DESIGN LOCATION	CODE NO	Description	Specification	Q'TY
1	F701	DE32-10037A	FUSE	FST 250V 3.15A	1
2	F701	DE47-40024A	HOLDER-FUSE	FH-51H 7.5A	1
3	IC01	DE13-20008A	IC-VOLT REGU	KA7812A	1
4	IC01	DE62-30032A	HEAT-SINK	AL H25	1
5	IC01	DE60-10100A	SCREW-PH	M3*6 FeFzY	1
6	IC02	DE13-10016A	IC-VOLT REGU	KA7805A	1
7	CR71	2306-000294	C-FILM	CQS 450V 1.5	1
8	FT71		FILTER NOISE	LSA05230P	1
9	R903	2001-000776	R-CARBON	RD 1/2 T(S) 471-J	1
10	R203	2001-000588	R-CARBON	RD 1/4 TP 332-J	1
11	R202,301,409,501~509,513,601,604,606,901	2001-000065	R-CARBON	RD 1/4 TP 103-J	17
12	R405,407	2001-000036	R-CARBON	RD 1/4 TP 331-J	2
13	R201,204,401,402,404,603,605	2001-000042	R-CARBON	RD 1/4 TP 102-J	7
14	R607	2001-000855	R-CARBON	RD 1/4 TP 560-J	1
15	R602	2001-001088	R-CARBON	RD 1/2 T(S) 102-J	1
16	R403	2001-000890	R-CARBON	RD 1/4 TP 682-J	1
17	R910,912	A1000-0244	R-CARBON	RD 1/8 TP 332-J	2
18	R406,408	2004-001137	R-METAL FILM	RD 1/4 TP 682-F	2
19	D101~105	0402-000137	DIODE-RECT	1N4007	5
20	SS71	B4190-0016	THYRISTOR	G3MB-202PL	1
21	BZ61	DE30-20016A	BUZZER	CBE 2220BA STICK	1
22	TN71	DE26-20154A	TRANS L.V	230V DC17V 300mA	1
23	TN71	DE60-60012A	PIN EYELET	OD2.5 L3.0	5
24	C202,402	2202-000783	C-CERAMIC	CA OA 50V 103Z	2
25	C301,401	2202-000796	C-CERAMIC	CA OA 50V 102Z	2
26	C102,104,201,203,403,404,501,502,901	2202-000780	C-CERAMIC	CA OA 50V 104Z	9
27	C103	2401-000710	C-ELEC	CE04 25V 222-M	1
28	C105	2401-001397	C-ELEC	CE 04 25V 471-M	1
29	C101	2401-000180	C-ELEC	CE 04 35V 102-M	1
30	C601	2401-001573	C-ELEC	47UF/50V	1
31	IC04	DE09-10149A	IC-MCU	MB89635R-466	1
32	IC03	DE13-20009A	IC	KA7533Z	1
33	X501	2802-000103	RSONATOR-CERAMIC	10MHz	1
34	IC05,IC06,IC07	DE13-20024A	IC-DRIVE	KID65003AP(KA2657)	3
35	Q201,401,601,602	A4050-0168	TR-GENERAL	KSC945Y	4
36	Q603	0501-000292	TRANSISTOR	A708Y	1
37	Q902, Q901	0504-000144	TRANSISTOR	R2002	2
38	SW91	3404-001013	SWITCH-TACT	KPT-1115V	1
39	CN73	3711-000262	CONNECTOR WAFER	YW396-05AV WHT	1
40	CN43	3711-000879	CONNECTOR WAFER	SMW250-03 BLU	1
41	CN41	3711-000940	CONNECTOR WAFER	SMW250-04(WHT)	1
42	CN61	3711-000999	CONNECTOR WAFER	SMW250-05 WHT	1
43	CN92	3711-001154	CONNECTOR WAFER	SMW250-09 WHT	1
44	TB71	DE59-30001A	CONNECTOR-TERMINAL	250TAP,1PIN	1
45	RY71	3501-001058	RELAY	DI1U DC12V	1
46	J1~J29,HR01,03,LR01	DE39-60001A	WIRE SO COPER	PI0.6 SN T 52MM	32
47	C701		C-MYLAR	224K	1
48	C702		C-MYLAR	104K	1
49	R904~906		R-CARBON	RD 1/2T(S) 621-J	3
50	CM71		CONNECTOR WAFER	YW396-03AV(BLK)	1
51	RY72	3501-000399	RELAY	JQ1a-12V	1

8-2 ASS'Y DISPLAY & Module PCB

8-2-1 AM24A1E12/AM26A1B09

• DB93-10560B



■ PART LIST

No	Description	CODE-NO	Specification	Q'TY
1	PCB-DISPLAY	DB41-10204B	FR-1 T1.6 W20 L170	1
2	LED - LAMP	0601-001333	LTL-30EHJ(ORG/GRN)	1
3	LED - LAMP	0601-001059	SY5511(YEL)	1
4	LED - LAMP	0601-001060	SM5511(GRN)	1
5	LED - LAMP	0601-001196	SO5511(ORG)	1
6	MODULE REMOCON	DB32-50027A	PNA4612MOOXD	1
7	C-CERAMIC	2202-000780	CA 0A 50V 104Z	2
8	R-CARBON	2001-000515	RD 1/8TP 221-J	2
9	CONNECTOR WAFER		YWL A200-09P	1
10	C-CERAMIC	2001-000283	CA 0A 50V 102Z	1
11	DIOD SWITCHING	0401-000005	1N4148	1
12	C/W DIS & MODULE	DB39-20346A	UL1007 AWG#26/9	1
13	CASE-CENTER PCB UP	DB61-10191A	PC, BLUE	1
14	CASE-CENTER PCB LOW	DB63-10494A	ABS, BLK	1
15	SEAL DISPLAY UPP	DB72-10233A	FOAM-PE, BLK	1
16	SEAL CASE DISPLAY	DB72-10220F	30FOAM-PE	1

8-2-2 AM24B1E12/AM26B1B09

• DB93-10561B



■ PART LIST

No	Description	CODE-NO	Specification	Q'TY
1	PCB-DISPLAY	DB41-10205B	FR-1 T1.6 W20 L170	1
2	LED - LAMP	0601-001333	LTL-30EHJ(ORG/GRN)	1
3	LED - LAMP	0601-001059	SY5511(YEL)	1
4	LED - LAMP	0601-001060	SM5511(GRN)	1
5	LED - LAMP	0601-001196	SO5511(ORG)	1
6	MODULE REMOCON	DB32-50027A	PNA4612MOOXD	1
7	C-CERAMIC	2202-000780	CA 0A 50V 104Z	2
8	R-CARBON	2001-000515	RD 1/8TP 221-J	2
9	CONNECTOR WAFER		YWL A200-09P	1
10	C-CERAMIC	2201-000283	CA 0A 50V 102Z	1
11	DIOD SWITCHING	0401-000005	1N4148	1
12	C/W DIS & MODULE	DB39-20346A	UL1007 AWG#26/9	1
13	CASE-CENTER PCB UP	DB61-10197A	PC, BLUE	1
14	CASE-CENTER PCB LOW	DB63-10494A	ABS, BLK	1
15	SEAL DISPLAY UPP	DB72-10245A	FOAM-PE, BLK	1
16	SEAL CASE DISPLAY	DB72-10220F	30FOAM-PE	1

9. Wiring Diagrams

9-1 Indoor Unit



9-2 Outdoor Unit



	ENGLISH	ESPANOL	FRANCAIS	ITALIANO
1	BLK	NEGRO	NOIR	NERO
2	RED	ROJO	ROUGE	ROSSO
3	WHT	BLANCO	BLANC	BIANCO
4	YEL	AMARILLO	JAUNE	GIALLO

UM24A1(B1)E2

CAPACITOR	FAN MOTOR : 4μF/450VAC
	COMP MOTOR : 30μF/420VAC

UM26A1(B1)B2

CAPACITOR	FAN MOTOR : 3.5μF/450VAC
	COMP MOTOR : 25μF/450VAC

UPDA TE LOG SHEET

Application date	Page	Part#	Note(Cause & Solution)	S/Bulletin#

Use this page to keep any special servicing information. (Service Bulletin, etc.)
If only parts number changes, Just change parts number directly on parts list.
And if you need more information, please see the service bulletin

Copyright

®œ 1995 by Samsung Electronics Co., Ltd.
All rights reserved.
This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, or
converted to any electronic or machine readable
from without prior written permission of Samsung Electronics Co., Ltd.

SyncMaster 17GLi/CMG7387L Service Manual
First edition June 1995.

Trademarks

Samsung is a registered trademark and SyncMaster 17GLi/CMG7387L and MacMaster
Cable Adapter are trademark of Samsung Electronics Co., Ltd.

Macintosh, Centris, Quadra, Duo Dock, and Power Macintosh are trademark of Apple computer, Inc.

All other trademarks are the property of their respective owners.

10. Schematic Diagrams

10-1 Indoor Unit




BATTERY
1.5X2
VDD
C101
47uF
ON/OFF
AIR CLEAN
CANCEL
OFF TIME
MODE
SET TEMP△
SET TIME
FAN SPEED
SET TEMP▽
QUICK TIMER
UP/DOWN SWING
SET TIMER
ON TIMER
TURBO/3WAY
TIME △
TIME ▽
MILD/SLEEP
SW5
SW4
SW1
SW2
SW3
OPTION1
OPTION2
TIME SHORT
K** : INPUT
P** : I/O
R** : OUTPUT
MICOM
LCD
SEG10 SEG11 SEG12 SEG13 SEG14 SEG15 SEG16 SEG17 SEG18 SEG19 SEG20 SEG21 SEG22 SEG23
COM0 COM1 COM2 COM3 SEG0 SEG1 SEG2 SEG3 SEG4 SEG5 SEG6 SEG7 SEG8 SEG9
SEG13 SEG12 SEG11 SEG10 SEG9 SEG8 SEG7 SEG6 SEG5 SEG4 SEG3 SEG2 SEG1 SEG0 COM3 COM2 COM1 COM0
K11 K10 K03 K02 K01 K00 P03 P02 P01 P00 R20 R13 R12 R11 R10 R03 R02 R01 R00
CC CB CA VL3 VL2 /RESET VADJ VL1 REM /RSTOUT AMPP AMPM AOUT VDD N.C OSC1 OSC2 VSS OSC3 OSC4 VS1
SEG4 SEG15 SEG16 SEG17 SEG18 SEG19 SEG20 SEG21 SEG22 SEG23 SEG24 SEG25 SEG26 SEG27 SEG28 SEG29 SEG30 SEG31 N.C /TEST K13 K12 K11
R501 60.4K-F
R502 60.4K-F
R503 60.4K-F
R504 60.4K-F
R505 60.4K-F*3
R506
R507
R508 30K-F
R509 30K-F*2
R510
R511 30K-F*3
R512
R513
R514 60.4K-F
R515 120K-F
R516 49.9K-F
R517 6.8K-F
TH01 103AT
TH1
TH2
C511 104Z
C512 104Z
X501 32.768KHz
X502 455KHz
C501 1uF
C502 104Z
C503 104Z
C504 104Z
C505 104Z
C506 104Z
C507 24P
C508 101J
C509 101J
C510 104Z
R601 1
R603 68
R604 1.2K
LE61 SI5312-H
LE62 SI5312-H
Q602 2SD1781K
Q601 C4375Y